# SCAN&GO surveying technology & solutions

# COAXIAL BRACKET for Trimble TX5, Faro Focus 3D, Faro X, Faro M serie



Coaxial Bracket for FARO S. FARO M serie



Coaxial Bracket for FARO FOCUS 3D, FARO X serie, TRIMBLE TX5



www.scom.go.eu

**USER MANUAL** 

### SCAN&GO srl

Via della Tecnica 34 A/B - 41051 Castelnuovo Rangone (MO) - Italy Cell. +39 3924627285 info@scan-go.eu

### **Coaxial Bracket**

Support designed to surmount laser scanner Trimble TX5 , Faro Focus 3D, Faro X, Faro S, Faro M with GNSS receiver or reflective prism at  $360^{\circ}$ .

Made following perfectly the shape of the instrument, the locking points are safe and non-invasive.

This support allows the simultaneous measurement of the position of the gripping point of the scanner, together with the scan itself, avoiding subsequent classic topographic operations for the union of scans made in sequence.

The low weight of the support and the equipment installed does not create any kind of mechanical or measuring problem during scans.

### Technical data

Maximum load: 10 KgAdaptor: 5/8" male





### **WARNING !!!!**

DO NOT USE THE COAXIAL BRACKET
AS A HANDLE
FOR THE SCANNER


The manufacturer is relieved from any liability in case of misuse of Coaxial Bracket



## Coaxial Bracket for FARO FOCUS 3D, FARO X serie, TRIMBLE TX5










Distance between the base of the GNSS receiver or prism 360° and center socket scanner



Particular of the adapter: Above: Junction 5/8 "male Below: Junction 5/8 "male

### **USE AND INSTALLATION INSTRUCTIONS**

Place the COAXIAL BRACKET above the laser scanner and screw the 4 external locking points at the maximum extention, which are positioned in the corners of aluminum structure.



# Coaxial Bracket for FARO S, FARO M serie







### **USE AND INSTALLATION INSTRUCTIONS**

Place the COAXIAL BRACKET above the laser scanner and screw the 4 external locking points at the maximum extention, which are positioned in the corners of aluminum structure.